

MANUAL STARTER BOX

MSB - Standard Features:

- NEMA 4X enclosure
- Push button ON & OFF
- Reset push button
- UL Listed
- Back panel, terminal strip
- IEC starter and adjustable overload
- Enclosure sizes: 12" x 10" x 6" up to 10 HP
14" x 12" x 8" for 15HP and up to 30HP



Overload will be pre-set at the factory to the pumps corresponding FLA rating.

| P/N | HP | VOLTS | PHASE | PUMP MODEL | AMP RANGE |
|----------|-----|-------|-------|----------------------|-----------|
| MSB1G060 | 0.5 | 115 | 1 | All 400's, 115 Volt | 5 to 7 |
| MSB1G130 | 1 | 115 | 1 | All 750's, 115 Volt | 12 to 14 |
| MSB1U070 | 1 | 230 | 1 | All 750's, 230 Volt | 6 to 8 |
| MSB1U140 | 2 | 230 | 1 | All 1500's, 230 Volt | 13 to 15 |
| MSB3U030 | 1 | 230 | 3 | All 08's, 230 Volt | 2 to 4 |
| MSB3T015 | 1 | 460 | 3 | All 08's, 460 Volt | 1 to 2 |
| MSB3U060 | 2 | 230 | 3 | All 15's, 230 Volt | 5 to 7 |
| MSB3T030 | 2 | 460 | 3 | All 15's, 460 Volt | 2 to 4 |
| MSB3U090 | 3 | 230 | 3 | All 22's, 230 Volt | 8 to 9.5 |
| MSB3T045 | 3 | 460 | 3 | All 22's, 460 Volt | 3.5 to 5 |
| MSB3U135 | 5 | 230 | 3 | All 37's, 230 Volt | 12 to 18 |
| MSB3T068 | 5 | 460 | 3 | All 37's, 460 Volt | 5.5 to 8 |
| MSB3U195 | 7.5 | 230 | 3 | All 55's, 230 Volt | 17 to 25 |
| MSB3T095 | 7.5 | 460 | 3 | All 55's, 460 Volt | 7 to 10 |
| MSB3U260 | 10 | 230 | 3 | All 75's, 230 Volt | 23 to 32 |
| MSB3T130 | 10 | 460 | 3 | All 75's, 460 Volt | 12 to 18 |
| MSB3T175 | 15 | 460 | 3 | KZN (H) 110-460T | 12 to 18 |
| MSB3T260 | 20 | 460 | 3 | KZN 150-460T | 23 to 32 |
| MSB3T400 | 30 | 460 | 3 | KZN 220-460T | 37 to 50 |

MSB numbering system: KZN 110, 3 phase, 460 volts, 17.5 amps = MSB3T175

Voltage code: G = 115, U = 230, T = 460

Other voltage combinations are available - Contact BJM Pumps

CONTACT BJM PUMPS FOR 208 / 575 BOXES