

## LWA-SERIES

Pos. No.	Part Description	Pump Model									
		LWA1500	LWA2200	LWA15	LWA22	LWA37	LWA55	LWA55H	LWA75	LWA75H	
		Item #	Item #	Item #	Item #	Item #	Item #	Item #	Item #	Item #	
1	CABLE, POWER, SJOW, 12/4 - 15M, LWA 2200	-	200099	-	-	-	-	-	-	-	
1	CABLE, POWER, SJOW, 14/4 - 15M, LWA 1500	200100	-	-	-	-	-	-	-	-	
1B	CABLE, POWER, ASSY., SOOW 14-5, 230, 460, 575V	-	-	200047	200047	-	-	-	-	-	
1B	CABLE, POWER, ASSY., SOOW 12-5, 230, 460, 575V	-	-	-	-	200055	-	-	-	-	
1B	CABLE, POWER, ASSY., SOOW 12-5, 460, 575V	-	-	-	-	-	-	-	200289	200289	
1B	CABLE, POWER, ASSY., SOOW 10-5, 230, 460, 575V	-	-	-	-	-	200062	200062	-	-	
2	BASE, CABLE	200087	200087	-	-	-	-	-	-	-	
3	COVER, MOTOR HOUSING, CI	200105	200105	200106	200106	200106	200107	200107	200107	200107	
6	BRACKET, LWA1500-2200	200095	200095	-	-	-	-	-	-	-	
7	STATOR, 10HP, 460/3/60, 3600 RPM, CLASS F	-	-	-	-	-	-	-	200154	200154	
7	STATOR, 10HP, 575/3/60, 3600 RPM, CLASS F	-	-	-	-	-	-	-	200155	200155	
7	STATOR, 2HP, 230/1/60, 3600 RPM, CLASS F	200156	-	-	-	-	-	-	-	-	
7	STATOR, 2HP, 230/460/ 3/60, 3600 RPM, CLASS F	-	-	200157	-	-	-	-	-	-	
7	STATOR, 2HP, 575/3/60, 3600 RPM, CLASS F	-	-	200158	-	-	-	-	-	-	
7	STATOR, 3HP, 230/1/60, 3600 RPM, CLASS F	-	200159	-	-	-	-	-	-	-	
7	STATOR, 3HP, 230/460/3/60, 3600 RPM, CLASS F	-	-	-	200160	-	-	-	-	-	
7	STATOR, 3HP, 575/3/60, 3600 RPM, CLASS F	-	-	-	200161	-	-	-	-	-	
7	STATOR, 5HP, 230/460/3/60, 3600 RPM, CLASS F	-	-	-	-	200162	-	-	-	-	
7	STATOR, 5HP, 575/3/60, 3600 RPM, CLASS F	-	-	-	-	200163	-	-	-	-	
7	STATOR, 7.5HP, 230/460/3/60, 3600 RPM, CLASS F	-	-	-	-	-	200164	200164	-	-	
7	STATOR, 7.5HP, 575/3/60, 3600 RPM, CLASS F	-	-	-	-	-	200165	200165	-	-	
9	ROTOR, SHAFT ASSY., 2HP, 1 PHASE, 304 SS	200142	-	-	-	-	-	-	-	-	
9	ROTOR, SHAFT ASSY., 2HP, 3 PHASE, 304 SS	-	-	200143	-	-	-	-	-	-	
9	ROTOR, SHAFT ASSY., 3HP, 1 PHASE, 304 SS	-	200144	-	-	-	-	-	-	-	
9	ROTOR, SHAFT ASSY., 3HP, 3 PHASE, 304 SS	-	-	-	200145	-	-	-	-	-	
9	ROTOR, SHAFT ASSY., 5HP, 3 PHASE, 304 SS	-	-	-	-	200146	-	-	-	-	
9	ROTOR, SHAFT ASSY., 7.5-10HP, 3 PHASE, 304 SS	-	-	-	-	-	200147	200147	200182	200182	
10	SWITCH, OVERLOAD 3HP, 230V, 1PH, LWA2200	-	200132	-	-	-	-	-	-	-	
10	SWITCH, OVERLOAD 2HP, 230V, 1PH	200175	-	-	-	-	-	-	-	-	
10A	SWITCH, OVERLOAD 5HP/230V, 10HP/460V, 3PH	-	-	-	-	200173	-	-	200173	200173	
10A	SWITCH, OVERLOAD 10HP, 575V, 3PH	-	-	-	-	-	-	-	200174	200174	
10A	SWITCH, OVERLOAD 2HP, 230V, 3PH	-	-	200176	-	-	-	-	-	-	
10A	SWITCH, OVERLOAD 3HP/230V, 5HP/460V, 3PH	-	-	-	200177	200177	-	-	-	-	
10A	SWITCH, OVERLOAD 2HP, 460V, 3PH	-	-	200178	-	-	-	-	-	-	
10A	SWITCH, OVERLOAD 3HP, 460V, 3PH	-	-	-	200179	-	-	-	-	-	
10A	SWITCH, OVERLOAD 2HP, 575V, 3PH	-	-	200180	-	-	-	-	-	-	

## LWA-SERIES

Pos. No.	Part Description	Pump Model									
		LWA1500 Item #	LWA2200 Item #	LWA15 Item #	LWA22 Item #	LWA37 Item #	LWA55 Item #	LWA55H Item #	LWA75 Item #	LWA75H Item #	
10A	SWITCH, OVERLOAD 3HP, 575V, 3PH	-	-	-	200181	-	-	-	-	-	
10A	SWITCH, OVERLOAD 5HP, 575V, 3PH	-	-	-	-	200184	-	-	-	-	
10A	SWITCH, OVERLOAD 7.5HP, 230V, 3PH	-	-	-	-	-	200185	200185	-	-	
10A	SWITCH, OVERLOAD 7.5HP, 460V, 3PH	-	-	-	-	-	200186	200186	-	-	
10A	SWITCH, OVERLOAD 7.5HP, 575V, 3PH	-	-	-	-	-	200187	200187	-	-	
10B	PLATE, OVERLOAD SWITCH	-	-	200133	200133	200133	200134	200134	200134	200134	
11	RETAINER, BEARING	200139	200139	200139	200139	202818	200141	200141	200141	200141	
12	SWITCH, CENTRIFUGAL	200171	200171	-	-	-	-	-	-	-	
13	COVER, CENTRIFUGAL SWITCH, LWA 1500-2200	200104	200104	-	-	-	-	-	-	-	
14A	CAPACITOR, RUN, LWA 1500-2200	200101	200101	-	-	-	-	-	-	-	
14B	CAPACITOR, START	200102	200103	-	-	-	-	-	-	-	
16	FRAME, MOTOR	200113	200113	200114	200114	200115	200116	200116	200116	200116	
18	HOUSING, OUTER W/ 3" NPT DISCH, 304SS	200120	200120	200121	200121	200119	-	-	-	-	
18	HOUSING, OUTER, 304SS	-	-	-	-	-	200122	200122	200122	200122	
19	BRACKET, BEARING	200183	200183	200183	200183	200093	200094	200094	200094	200094	
20A	BEARING, UPPER, LWA	200088	200088	200088	200088	200088	200959	200959	200959	200959	
20B	BEARING, LOWER, LWA	200959	200959	200959	200959	200968	200963	200963	200963	200963	
21	SEAL, MECH., SI/SI X CARB/CER	200151	200151	200151	200151	200152	200153	200153	200153	200153	
24	BUSHING, LIP SEAL, 304SS	200096	200096	200096	200096	200097	200098	200098	200098	200098	
25	SEAL, LIP	200148	200148	200148	200148	200149	200150	200150	200150	200150	
26	VOLUTE, HARDENED DI	200188	200188	200188	200188	200189	200190	200190	200190	200190	
27	IMPELLER, HI CHROME CI	200123	200124	200123	200124	200125	200128	200127	200129	200126	
28	COVER, SUCTION, HARDENED DI	200108	200108	200108	200108	200109	-	200112	-	-	
28	COVER, SUCTION WITH WEAR RING PRESSED	-	-	-	-	-	200111	-	200110	200111	
29	PLATE, WEAR HI CHROME CI	-	-	-	-	-	-	200136	-	-	
31	STRAINER, BOTTOM COVER	200166	200166	200166	200166	200166	200168	200168	200168	200168	
37	ADAPTER, DISCHARG, 4", MALE NPT	-	-	-	-	-	200082	-	-	200082	
37	ADAPTER, DISCHARGE, 3" MALE NPT	-	-	-	-	-	-	200083	-	-	
37	ADAPTER, DISCHARGE, 6" MALE NPT	-	-	-	-	-	-	-	200084	-	
39	AGITATOR, HARDENED DI	200085	200085	200085	200085	200085	200086	200086	200086	200086	
41	HANDLE, LIFT	200117	200117	200117	200117	200117	200118	200118	200118	200118	
46	KEY, IMPELLER	200130	200130	200130	200130	200131	200131	200131	200131	200131	
47	KIT, O-RING	200211	200211	200212	200212	200212	200213	200213	200213	200213	
53C	WASHER, FLAT	-	-	-	-	-	202910	202910	202910	202910	
53E	SPACER WASHER (LOWER BEARING)	-	-	-	-	-	200997	200997	200997	200997	
53F	SPACER WASHER (LOWER BEARING)	200995	200995	200995	200995	200996	-	-	-	-	
54B	WASHER, LOCK	-	-	-	-	-	202909	202909	202909	202909	
55	PLUG, OIL, LWA	200138	200138	200138	200138	200138	200138	200138	200138	200138	
55H	STUB, AGITATOR JOINT	-	-	200169	200169	200169	-	-	200170	200170	
55J	STUD	-	-	-	-	-	202814	202814	202814	202814	
55L	STUB, AGITATOR JOINT	200169	200169	-	-	-	200170	200170	-	-	
56B	NUT	-	-	-	-	-	202899	202899	202899	202899	
64	BRACKET, OVERLOAD (460V & 575V MOTOR ONLY)	-	-	-	-	-	203376	203376	203376	203376	

# LWAE-SERIES

Pos. No.	Part Description	Pump Model	LWAE15	LWAE22	LWAE37
		Item #	Item #	Item #	Item #
1	CABLE, POWER, SJOW, 12/3 - 15M, LWA 2200	-	-	-	-
1	CABLE, POWER, SJOW, 14/3 - 15M, LWA 1500	-	-	-	-
1B	CABLE, POWER, ASSY., SOOW 14-5, 230, 460, 575V	204225	204225	-	-
1B	CABLE, POWER, ASSY., SOOW 12-5, 230, 460, 575V	-	-	200289	-
2	BASE, CABLE	-	-	-	-
3	COVER, MOTOR HOUSING, CI	204269	204269	204270	-
6	BRACKET, LWA1500-2200	-	-	-	-
7	STATOR, 2HP, 230/1/60, 3600 RPM, CLASS F	-	-	-	-
7	STATOR, 2HP, 230/460/ 3/60, 3600 RPM, CLASS F	204274	-	-	-
7	STATOR, 2HP, 575/3/60, 3600 RPM, CLASS F	204275	-	-	-
7	STATOR, 3HP, 230/1/60, 3600 RPM, CLASS F	-	-	-	-
7	STATOR, 3HP, 230/460/3/60, 3600 RPM, CLASS F	-	204276	-	-
7	STATOR, 3HP, 575/3/60, 3600 RPM, CLASS F	-	204277	-	-
7	STATOR, 5HP, 230/460/3/60, 3600 RPM, CLASS F	-	-	-	204278
7	STATOR, 5HP, 575/3/60, 3600 RPM, CLASS F	-	-	-	204279
9	ROTOR, SHAFT ASSY., 2HP, 1 PHASE, 304 SS	-	-	-	-
9	ROTOR, SHAFT ASSY., 2HP, 3 PHASE, 304 SS	204282	-	-	-
9	ROTOR, SHAFT ASSY., 3HP, 1 PHASE, 304 SS	-	-	-	-
9	ROTOR, SHAFT ASSY., 3HP, 3 PHASE, 304 SS	-	204283	-	-
9	ROTOR, SHAFT ASSY., 5HP, 3 PHASE, 304 SS	-	-	-	204284
10	SWITCH, OVERLOAD 3HP, 230V, 1PH, LWA2200	-	-	-	-
10	SWITCH, OVERLOAD 2HP, 230V, 1PH	-	-	-	-
10A	SWITCH, OVERLOAD 5HP, 230V, 3PH	-	-	-	204316
10A	SWITCH, OVERLOAD 2HP, 230V, 3PH	204311	-	-	-
10A	SWITCH, OVERLOAD 3HP, 230V, 3PH	-	204312	-	-
10A	SWITCH, OVERLOAD 2HP, 460V/575V, 3PH	204310	-	-	-
10A	SWITCH, OVERLOAD 3HP, 460V, 3PH	-	204313	-	-
10A	SWITCH, OVERLOAD 3HP, 575V, 3PH	-	204314	-	-
10A	SWITCH, OVERLOAD 5HP, 460/575V, 3PH	-	-	-	204315
10B	PLATE, OVERLOAD SWITCH	204330	204330	204331	-
11	RETAINER, BEARING	200139	200139	204285	-
12	SWITCH, CENTRIFUGAL	-	-	-	-
13	COVER, CENTRIFUGAL SWITCH, LWA 1500-2200	-	-	-	-
14A	CAPACITOR, RUN, LWA 1500-2200	-	-	-	-
14B	CAPACITOR, START	-	-	-	-
16	FRAME, MOTOR	204287	204287	204288	-
18	HOUSING, OUTER, 304SS	204291	204291	204292	-
19	BRACKET, BEARING	204293	204293	204294	-
20A	BEARING, UPPER, LWA	200088	200088	200088	-
20B	BEARING, LOWER, LWA	200959	200959	200968	-
21	SEAL, MECH., SI/SI X CARB/CER	204295	204295	204295	-
24	BUSHING, LIP SEAL, 304SS	200096	200096	200096	-
25	SEAL, LIP	204296	204296	204296	-

\*\*All 1 HP and up BJM mechanical seal elastomer material is FKM

## LWAE-SERIES

26	VOLUTE, HARDENED DI	204297	204297	204297
27	IMPELLER, HI CHROME CI	204298	204299	204300
28	COVER, SUCTION WITH WEAR RING PRESSED	204301	204301	204301
31	STRAINER, BOTTOM COVER	204302	204302	204302
37	ADAPTER, DISCHARGE, 3" MALE NPT	204646	204646	204646
39	AGITATOR, HARDENED DI	204303	204303	204303
41	HANDLE, LIFT	204304	204304	204304
46	KEY, IMPELLER	204305	204305	204305
47	KIT, O-RING	204307	204307	204307
53F	SPACER WASHER (LOWER BEARING)	204320	204320	200996
55	PLUG, OIL, LWA	200138	200138	200138
55H	STUB, AGITATOR JOINT	204321	204321	204321
55L	STUB, AGITATOR JOINT	-	-	-